

Cleaning instructions



Outside cleaning: Spray the outside of the basin with the Urimat product for cleaning and maintenance.



Wipe it with clean household paper.



If present always clean the sensor



Remove the sieve and clean it.



Inside cleaning: Spray the basin with the Urimat product for cleaning and maintenance.



Clean the basin and the visible black seal with clean household paper.

Important:

Clean the seal only.

Do not (!) remove it.



Insert the clean or new sieve



Finally spray the basin inside with the Urimat product for cleaning and maintenance, but do not wipe.



Finish!

Important !

The MB-Cleaning Agent is a concentrate and keep the sanitary environment clean and odorfree

The MB-Cleaning Agent dilution is (1:20) with water



As with any technical products a regular maintenance is the key to long error-free operation and protection of your investment

Head Office

URIMAT Schweiz AG
Feldbachstrasse 81
CH-8714 Feldbach
Tel. +41 (0)55 251 52 30
Fax +41 (0)55 251 52 31
info@urimat.com www.urimat.com

Replacement of siphon

1 Preparation

Grease the board of new siphon with the URIMAT sanitary grease ...
and the refill with water.



2 Replacement of siphon



Rinse with about 2 liters of water possible.



Remove sieve.



Remove siphon.



Empty siphon and put it into the plastic bag and deposit it into dustbin.



Add the prepared siphon



Important!
Insert new siphon and press to the latch.

Important!

Oppress correctly the board of siphon.



Replace cleaned or new sieve.



Control the function by pouring about 2 liters of water into the basin.



Finish.

A regular control and care of the URIMAT guarantees its perfect function



Tel. +41 (0) 55 251 52 30 • info@urimat.com